

EV PORTABLE CHARGER

TYPE 2 Plug













The blue button is the adjustment current button, Push the blue button to change the current. When you adjust the current, IEC 62196-2 plug is disconnected, the power plug is always connected. When you get to the amperage you want, plug it in and start charging.



SPECIFICATIONS:

Power Phase: Model No.: Working Voltage: Rated Current: Insulation Resistance: Resistance Voltage: Contact resistance: Insertion and Extraction Force 1-Phase ALV21PT2 110V~250V 8-10-13-16A >1000MΩ 2000V less than 0.5mΩ 80N<F<100N

Main Material:

Cable Spec.: Cable Length: IP-class: Fire rating: Operating Temperature: Net Weight: Thermo Plastic/Silicon Rubber / CopperAlloy 3*2.5mm2+2*0.5mm2 8m 54 UL94 V-0 (-30°C ~ 50°C) 2.8 kg